

29

Date: Thursday, 6/21/2007 2:28:44 PM
 User: Kim Johnston

Process Sheet

Customer : CU-DAR001 Dart Helicopters Services Drawing Name : ARMOR SHIELD
 Job Number : 33045
 Estimate Number : 12378
 P.O. Number : N/A Part Number : D206667203A
 This Issue : 6/21/2007 S.O. No. : N/A Drawing Number : DSI9326
 Prsht Rev. : NC Project Number : N/A
 First Issue : N/A Type : LANDING GEAR Drawing Revision : A
 Previous Run : 32927 Material : 29/06
 Due Date : 7/20/2007 Qty: 1 Um: Each
 Written By :
 Checked & Approved By : 07.06.22
 Comment : Est Rev:A New Issue 06-04-19 JLM

Additional Product

Job Number:



Seq. #: Machine Or Operation: Description :

1.0 DC DOCUMENT CONTROL



Comment: Photocopy bluefile & type labels per PPPD206-667-203A CHG001
 Add DSI 9326 to existing paper work.

07.07.03

2.0 D206667203 Crosstube Installation



Comment: Qty.: 1.0000 Each(s)/Unit Total : 1.0000 Each(s)
 Fwd Crosstube
 Batch: 32671

85 07-06-30

3.0 HAND FINISHING1 HAND FINISHING RESOURCE #1



Comment: HAND FINISHING RESOURCE #1
 1-Remove tube from packaging

2-Apply Armor shield as per DSI 9326
 A/R Armor Shield Batch: 104535

} 85 07-06-31

4.0 QC14 INSPECT SPRAY PAINT



Comment: Inspect Spray Paint

m/c 07/07/03

①

5.0 PACKAGING 1 PACKAGING RESOURCE #1



Comment: PACKAGING RESOURCE #1
 Identify and pack for shipping as per PPP D206-667-203A
 Location: DRAFT
 PPP Rev: 7/7/03 ①

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes ☐ No ☒ DQA: ☒ Date: 21/07/03
 QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Date: Thursday, 6/21/2007 2:28:44 PM
User: Kim Johnston

Process Sheet

Customer: CU-DAR001 Dart Helicopters Services

Drawing Name: ARMOR SHIELD

Job Number: 33045

Part Number: D206667203A

Job Number:



Seq. #:

Machine Or Operation:

Description :

6.0

QC21

FINAL INSPECTION/W/O RELEASE



Comment: FINAL INSPECTION/W/O RELEASE

07/07/03

Job Completion



07/07/03

DART		TEL: 1-613-632-3336 FAX: 1-613-632-4443	
TRANSPORT CANADA APPROVAL 0-03-89			
P/N	D206-667-203BL	CHG	CHG002
DESC	Crosstube Aft High	SIC	SH01-5
LOT	B32671	SIC	SR01304NY
MODEL	Bell 206L/L1/L3/L4	SIC	
MADE IN CANADA			

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

DART

DESIGN <i>PH</i>	DRAWN BY <i>PH</i>	DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA	
CHECKED <i>J.J.</i>	APPROVED <i>PH</i>	DRAWING NO. DSI 9326	REV. A SHEET 1 OF 1
DATE 06.02.14		TITLE ARMOR SHIELD	SCALE NTS
A	06.02.14	NEW ISSUE	

DART SERVICE INSTRUCTION

To further protect Dart crosstubes from mechanical damage in service, they may be treated with "Armor Shield" surface treatment.

INSTALLATION	CANADIAN STC	FAA STC
D205-596-101/-103/-105/-107	SH03-6	SR01742NY
D212-664-101/-201 D412-664-203	SH01-9	SR01298NY
D206-667-101/-103/-201/-203 D407-667-105/-205	SH01-5	SR01304NY
D058-676-101/-201	N/A	SR01018SE

To designate crosstubes with 'Armor Shield' add 'A' to the Part Number. For example, D206-667-101A is a D206-667-101 crosstube coated with Armor Shield. It is acceptable to apply the Armor Shield in regions shown in Figure 1 only. It is **NOT** acceptable to apply Armor Shield in the cuff and support/clamp regions.

1.0 To apply Armor Shield

- 1) Ensure the crosstube is appropriately finished in accordance with the relevant manufacturing drawing or Instruction for Continued Airworthiness (ICA).
- 2) Mask areas around supports and cuffs per Figure 1. Abrade paint finish in areas requiring protection using 320 grit sandpaper.
- 3) Clean/degrease surface of crosstube using Methyl Ethyl Ketone (MEK), 4105S Wash'n'Wipe Degreaser, or equivalent and wipe the surface to clean the entire area
- 4) Apply 3 coats of Proform PF 746 or PF 746-1 to surface (apply additional coats when surface is dry, but not fully cured)
- 5) Allow 5 hours for coating to dry.
- 6) Apply 2 coats of Imron 500s Polyurethane Enamel clear + Dupont Imron Polyurethane Enamel Activator 192S (mix 3:1). Mix 15 minutes prior to application and allow 15 minutes before applying additional coats.

2.0 Armor Shield removal/re-application

To remove the Armor Shield coating or if damage to the coating and/or crosstube is observed during inspection.

- 1) Remove Armor Shield from the affected area using 80 grit sandpaper. To remove Armor Shield from larger areas, bead blasting has been determined to be the most effective technique.
- 2) Repair mechanical damage (within limits) to the crosstube and touch up finish in accordance with the relevant ICA.
- 3) Apply Armor Shield in accordance with Section 1.0 of these instructions.




FIGURE 1 - ACCEPTABLE REGIONS TO BE COATED WITH ARMOR SHIELD

CANADA DEPARTMENT OF TRANSPORT AIRCRAFT CERTIFICATION BRANCH DAO # 01-O-01	
APPROVED	
BY:	<i>[Signature]</i> D. SHEPHERD (DE # 02)
DATE:	06.02.14
CERT. NO.:	SH03-6/SH01-9/SH01-5
ISSUE NO.:	3/3/3

Copyright © 2006 by DART AEROSPACE LTD

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.